

QC-HS / QC-MS - hurtigskifte MS

Modeller og specifikationer

Model	Betjening	Maskinklas se [t]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	F [mm]	Vægt [kg]	Tiltstørrel se	Holdemom ent [Nm]	Arbejdstry k [bar]	Tiltvinkel [°]
QC-HS-01	Automatisk	0,9-2,0	235	180	40	-	-	-	20	-	-	-	-
QC-HS-03	Automatisk	2,0-6,0	295	200	50	-	-	-	30	-	-	-	-
QC-HS-08	Automatisk	6,0-12	400	290	60	-	-	-	90	-	-	-	-
QC-HS-10	Automatisk	10-19	520	395	70	-	-	-	200	-	-	-	-
QC-HS-21	Automatisk	18-28	545	495	80	-	-	-	310	-	-	-	-
QC-HS-25	Automatisk	26-40	545	600	80	-	-	-	310	-	-	-	-
QC-MS-01	Manuel	0,9-2,0	235	180	40	-	-	-	20	-	-	-	-
QC-MS-03	Manuel	2-6	295	200	50	-	-	-	30	-	-	-	-
QC-MS-08	Manuel	6-12	400	290	60	-	-	-	90	-	-	-	-
QC-MS-10	Manuel	10-19	520	395	70	-	-	-	200	-	-	-	-
QC-MS-21	Manuel	18-28	545	495	80	-	-	-	310	-	-	-	-
QC-U-HS-01	Tilt / drej	0,9-2,0	235	180	40	260	227	318	46	100	2,4	210	180
QC-U-HS-03	Tilt / drej	2,0-6,0	295	200	50	335	252	398	90	125	8,2	210	180
QC-U-HS-08	Tilt / drej	6,0-12	400	290	60	580	365	540	232	200	24,0	210	180
QC-U-HS-10	Tilt / drej	10-19	520	395	70	510	498	702	402/436	250	40,0	250	100/140
QC-U-HS-21	Tilt / drej	18-28	545	495	80	580	624	735	644/684	270	54,0	250	100/140

Tal som trykt i denne families datablad. En streg betyder, at databladet ikke angiver tallet.