

QC-HS / QC-MS - snelwissel MS

Modellen en specificaties

Model	Bediening	Machinekla sse [t]	A [mm]	B [mm]	C [mm]	D [mm]	E [mm]	F [mm]	Gewicht [kg]	Kantelmaa t	Houdkoppe l [Nm]	Werkdruk [bar]	Kantelhoek [°]
QC-HS-01	Automatisch	0,9-2,0	235	180	40	-	-	-	20	-	-	-	-
QC-HS-03	Automatisch	2,0-6,0	295	200	50	-	-	-	30	-	-	-	-
QC-HS-08	Automatisch	6,0-12	400	290	60	-	-	-	90	-	-	-	-
QC-HS-10	Automatisch	10-19	520	395	70	-	-	-	200	-	-	-	-
QC-HS-21	Automatisch	18-28	545	495	80	-	-	-	310	-	-	-	-
QC-HS-25	Automatisch	26-40	545	600	80	-	-	-	310	-	-	-	-
QC-MS-01	Handmatig	0,9-2,0	235	180	40	-	-	-	20	-	-	-	-
QC-MS-03	Handmatig	2-6	295	200	50	-	-	-	30	-	-	-	-
QC-MS-08	Handmatig	6-12	400	290	60	-	-	-	90	-	-	-	-
QC-MS-10	Handmatig	10-19	520	395	70	-	-	-	200	-	-	-	-
QC-MS-21	Handmatig	18-28	545	495	80	-	-	-	310	-	-	-	-
QC-U-HS-01	Kantelen / draaien	0,9-2,0	235	180	40	260	227	318	46	100	2,4	210	180
QC-U-HS-03	Kantelen / draaien	2,0-6,0	295	200	50	335	252	398	90	125	8,2	210	180
QC-U-HS-08	Kantelen / draaien	6,0-12	400	290	60	580	365	540	232	200	24,0	210	180
QC-U-HS-10	Kantelen / draaien	10-19	520	395	70	510	498	702	402/436	250	40,0	250	100/140
QC-U-HS-21	Kantelen / draaien	18-28	545	495	80	580	624	735	644/684	270	54,0	250	100/140

Waarden zoals vermeld op het productblad van deze familie. Een streepje betekent dat het productblad die waarde niet vermeldt.